


INSTRUCTIONS ON SETTING UP MOON WALK



1. THANK YOU FOR RENTING OUR MOONWALK

2. A FEW FACTS ABOUT THE MOONWALK

a. THE MOONWALK MEASURES 15 FOOT SQUARE

b. THE BLOWER RUNS CONSTANTLY TO KEEP INFLATED

c. WE INCLUDE 4 STAKES FOR GRASS APPLICATIONS. DO NOT STAKE MOON WALK UNTIL FULLY INFLATED, DON'T WORRY, IT WON'T FLOAT AWAY.

d. IT ONLY TAKES A MATTER OF MINUTES TO FULLY INFLATE

3. ROLL OUT AND UNFOLD THE MOONWALK

4. MOVE INTO DESIRED LOCATION.

5. CONNECT BLOWER TO ONE TUBE, AND CLOSE OFF THE SECOND ONE WITH THE INCLUDED STRAP.

6. ONLY USE THE 50' EXTENSION CORD SUPPLIED BY RAYBORN ACE HARDWARE. IF YOU EXCEED 50', ANY DAMAGE TO THE BLOWER IS NOT COVERED BY YOUR DAMAGE WAIVER.

7. ONCE FULLY INFLATED, STAKE DOWN TO PREVENT MOVEMENT WHILE IN USE.

8. HAVE FUN!